

INDEX

ROVER SERVICE NEWS LETTERS Nos. 93-96 INCLUSIVE

This Index is intended to give a guide to items which have been circulated by means of Rover Service News Letters Nos. 93-96 inclusive.

It details the heading and item numbers for each particular item dealt with and the News Letter numbers in which any reference to that subject has appeared.

	<i>Description</i>	<i>Models</i>	<i>News Letter Number</i>	<i>Item Number</i>
B				
	Bell housing drain plug	Land-Rover	94	431
	Bolts, rear main bearing cap	Land-Rover	94	425
	Brake and clutch, reservoir tank	Land-Rover	93	417
	Brakes, rear	Car	94	432
C				
	Clutch and brake reservoir tank	Land-Rover	93	417
	Cold starting, Diesel engine	Land-Rover	94	426
D				
	Diesel engine, cold starting	Land-Rover	94	426
	Distributor pump timing	Land-Rover Diesel	93	415
	Drain plug, bell housing	Land-Rover	94	431
E				
	Equipment, extra	Land-Rover	96	444
	Exhaust silencer	Land-Rover	94	434
	Exhaust tail pipe	Car	94	435
	Exterior sun visor	Land-Rover	94	419, 423
	Extra equipment	Land-Rover	96	444
G				
	Gearbox	Car	94	430
	Grease nipple, propeller shaft	Land-Rover	94	433
L				
	Lock stop, steering	Land-Rover	96	443
	Lubricants, recommended	Land-Rover Diesel	94	429
M				
	Main bearing cap fixing bolts	Land-Rover	94	425
	Mud flaps for wings	Land-Rover	94	420, 424
N				
	New models	Car	96	441, 445
O				
	Oil pressure switch	Car and Land-Rover	95	439
	Oil recommendations	Land-Rover Diesel	94	429
P				
	Pistons	Car and Land-Rover	94	427
	Plastic cover, Owner's Instruction Manual	Land-Rover	94	422
	Plastic cover, Parts Catalogue and Price List	Car and Land-Rover	94	421
	Plugs, sparking	Car	94	428
	Propeller shaft grease nipple	Land-Rover	94	433
	Pump, distributor timing	Land-Rover Diesel	93	415
R				
	Rear brakes	Car	94	432
	Recommended lubricants	Land-Rover Diesel	94	429
	Reservoir tank, brake and clutch	Land-Rover	93	417
	Road wheel	Car	94	436

INDEX ROVER SERVICE NEWS LETTERS Nos. 93-96 INCLUSIVE

	<i>Description</i>		<i>Models</i>	<i>News Letter Number</i>	<i>Item Number</i>
S					
	Silicone M.S.4 Compound.... Car and Land-Rover	95	440
	Sparking plugs Car	94	428
	Steering lock stop Land-Rover	96	443
	Sun visor, exterior Land-Rover	94	419, 423
	Switch, oil pressure Car and Land-Rover	95	439
T					
	Tail pipe exhaust.... Car	94	435
	Timing, distributor pump Land-Rover Diesel	93	415
V					
	Visor, sun, exterior Land-Rover	94	419, 423
W					
	Wheel, road Car	94	436
	Wing, mud flap Land-Rover	94	420, 424